



ZINKO


Hydraulic Jack

ZATJ-22S-4v2 Parts Breakdown


Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 032316 page 1 of 2

Jack Assembly



Air Pump





ZATJ-22S-4v2 Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 032316 page 2 of 2

Jack Assembly

No.	Part #	Description
1	90602204 - 1	FRAME ASSY
2	90602204 - 2	COVER
3	9060220S - 4	WASHER
5	90602204 - 5	BOLT
6	90602204 - 6	SHAFT
7	90602204 - 7	WHEEL
8	9060220S - 9	WASHER
9	90602204 - 9	C-RING
10	90602204 - 10	VALVE BLOCK
11	9060220S - 13	*O-RING
12	9060220S - 14	SPRING WASHER
13	9060220S - 15	BOLT
14	9060220S - 16	VALVE BALL
15	9060220S - 99	SCREW
16	9060220S - 17	PIECE
17	9060220S - 18	VALVE BALL
18	9060220S - 19	VALVE SPRING-A
19	9060220S - 20	COPPER PACKING
20	90602204 - 20	BOLT
21	9060220S - 22	VALVE BALL
22	9060220S - 23	S.V.BALL SEAT
23	9060220S - 24	S.V.SPRING
24	9060220S - 25	S.V. ADJUSTING SCREW
25	90602204 - 25	*S.V.PACKING
26	90602204 - 26	PUSH NUT

No.	Part #	Description
27	9060220S - 28	*O-RING
28	90602204 - 28	RELEASE STEM
29	9060220S - 30	OIL PLUG
30	90602204 - 30	SPRING WASHER
31	90602204 - 31	BOLT
32	9060220S - 34	*O-RING
33	9060220S - 42	RAM
34	9060220S - 43	*BACKUP RING
35	9060220S - 44	*PACKING
36	9060220S - 91	RAM GUIDE RING
37	9060220S - 92	SNAP RING
38	9060220S - 45	STUFFING NUT
39	9060220S - 46	*O-RING
40	9060220S - 47	*DUST SEAL
41	9060220S - 48	SLEEVE
42	9060220S - 49	ADJUSTING SCREW
43	9060220S - 51	HANDLE SOCKET
44	90602204 - 44	UNIVERSAL JOINT
45	9060220S - 54	HI-TEN BOLT
46	9060220S - 55	WASHER
47	9060220S - 56	NUT
48	90602204 - 48	SPRING WASHER
49	9060220S - 58	BOLT
50	9060220S - 59	HANDLE
51	9060220S - 60	RELEASE ROD
52	9060220S - 61	KNOB

No.	Part #	Description
53	9060220S - 62	SCREW
54	9060220S - 63	SPRING WASHER
55	9060220S - 64	LEVER
56	9060220S - 65	TUBE
57	9060220S - 66	WASHER
58	9060220S - 67	SPRING
59	9060220S - 68	COTTER PIN
60	9060220S - 69	LOCK PIN
61	9060220S - 70	COTTER PIN
62	9060220S - 57	SPRING PIN
63	9060220S - 96	RING
64	9060220S - 71	VALVE BODY
65	9060220S - 77	AIR VALVE
66	9060220S - 95	AIR HOSE
67	9060220S - 82	ELBOW
68	9060220S - 85	TUBE
69	9060220S - 94	SPRING HANGER
70	9060220S - 93	RETURN SPRING
101	90602204 - 101	JACK ASSY
102	9060220S - 102	HANDLE ASSY
103	90602204 - 103	VALVE BLOCK ASSY
104	9060220S - 104	AIR PUMP ASSY
105	9060220S - 105	AIR VALVE ASSY
106	90602204 - 106	REPAIR KITs (All *)
AD	90602204 - AD	*ADAPTOR KIT ₁

₁ (Set of 2) consisting of 9060220S-AD1 and 9060220S-AD3.

Air Pump

No.	Part #	Description
1	9060667 - 1	*NUT
2	9060667 - 2	BOTTOM CAP
3	9060667 - 3	ADJUST PIN
4	9060667 - 4	CAP SCREW
5	9060667 - 5	*SEAL RING
6	9060667 - 6	*BACKUP RING
7	9060667 - 7	*U-CUP RING
8	9060667 - 8	*O-RING
9	90602204 - 9	*CYLINDER BOLT
10	9060667 - 10	*SILENCER
11	9060667 - 11	U STYLE GASKET

No.	Part #	Description
12	9060667 - 12	SPRING
13	9060667 - 13	*CUSHION
14	9060667 - 14	PISTON PLATE
15	9060667 - 15	*O-RING
16	9060667 - 16	PISTON ROD
17	9060667 - 17	*O-RING
18	9060667 - 18	PISTON B
19	9060667 - 19	*PACKING
20	9060667 - 20	*O-RING
21	9060667 - 21	VALVE
22	9060667 - 22	PISTON A

No.	Part #	Description
23	9060667 - 23	*PILOT PISTON CUSHION
24	9060667 - 24	SCREW
25	9060667 - 26	HEX SCREW
26	9060667 - 27	SPRING
27	9060667 - 28S	CYLINDER SET
28	90602204 - 71	ELBOW
29	9060667 - 34	AIR HOSE
30	9060667 - 35S	AIR SWITCH SET
31	9060667 - 38	QUICK COUPLER
32	90602204 - RP	REPAIR KITS (ALL *)