




ZNP Series Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807
Page 1 of 2





ZNP Series Parts List

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807
Page 2 of 2

MODEL	ZNP-2 (2 Ton)	ZNP-3 (3 Ton)	ZNP-4 (4 Ton)	ZNP-5 (5 Ton)	ZNP-8 (8 Ton)	ZNP-12 (12 Ton) LOW	ZNP-17 (17 Ton)	ZNP-22 (22 Ton) LOW
# Parts Description								
1) Body Assy	N/A							
2) Pump Plunger	ZN002-2				ZN008-2			ZN022-2
3) Pump Backup Ring	ZN002-3				ZN008-3			
4) Pump Packing	ZN002-4				ZN008-4			
5) Pump Plunger Pin	ZN002-5				ZN008-5			ZN022-5
6) Pump Stay Pin	ZN002-6				ZN008-6			ZN022-6
7) Handle Socket Assy	ZN002-7				ZN008-7			ZN022-7
8) Handle	ZN002-8	ZN003-8			ZN008-8			ZN022-8
9) Snap Ring/Push Nut	ZN002-9				ZN008-9			ZN022-9
10) Valve Ball	N/A							
11) Valve Spring	N/A							
12) Valve Plug	N/A							
13) Push Nut	ZN002-13				N/A			
14) Release Packing	ZN002-14							
15) Release Assy	ZN002-15							
16) Ram	ZN002-16	ZN003-16	ZN004-16	ZN005-16	ZN008-16	ZN012-16	ZN017-16	ZN022-16
17) Ram Packing Seat	ZN002-17	ZN003-17	ZN004-17	ZN005-17	ZN008-17	ZN012-17	ZN017-17	ZN022-17
18) Ram Backup Ring	ZN002-18	ZN003-18	ZN004-18	ZN005-18	ZN008-18	ZN012-18	ZN017-18	ZN022-18
19) Ram Packing	ZN002-19	ZN003-19	ZN004-19	ZN005-19	ZN008-19	ZN012-19	ZN017-19	ZN022-19
20) Ram Packing Stopper	ZN002-20	ZN003-20	ZN004-20	ZN005-20	ZN008-20	ZN012-20	ZN017-20	ZN022-20
21) Snap Ring	ZN002-21	ZN003-21	ZN004-21	ZN005-21	ZN008-21	ZN012-21	ZN017-21	ZN022-21
22) Stuffing Ring	ZN002-22	ZN003-22	ZN004-22	ZN005-22	ZN008-22	ZN012-22	ZN017-22	ZN022-22
23) Cylinder Packing	ZN002-23	ZN003-23	ZN004-23	ZN005-23	ZN008-23	ZN012-23	ZN017-23	ZN022-23
24) Stopper Ring	ZN002-24	ZN003-24	ZN004-24	ZN005-24	ZN008-24	ZN012-24	ZN017-24	ZN022-24
25) Adjusting Screw Assy	ZN002-25	ZN003-25	ZN004-25	ZN005-25	ZN008-25	ZN012-25	ZN017-25	ZN022-25
26) Supporting Plate	N/A							
27) Snap Ring	N/A							
28) Oil Plug	ZN002-28							
29) Horizontal Pin	N/A						ZN017-29	ZN022-29
30) Vertical Pin	N/A						ZN017-30	ZN022-30
31) Ram Spring	N/A						ZN017-31	
32) Ram Spring Stopper	N/A						ZN017-32	
33) Ram Assy	ZN002-33		ZN004-33	ZN005-33	ZN008-33	ZN012-33	ZN017-33	ZN022-33
34) Pin Handle Socket	ZN002-34				N/A			
35) Safety Valve Ball	N/A							
36) Safety Valve Ball Seat	N/A							
37) Safety Valve Spring	N/A							
38) Adj. Screw Safety Valve	N/A							
39) Safety Valve Plug	N/A							